




## ELECTRICAL SYSTEM

	Page Number
<b>ALTERNATOR</b>	
Alternator Belt Adjustment . . . . .	6-3
Checking Alternator Output . . . . .	6-4
Checking Alternator Regulator . . . . .	6-4
Checking Alternator Wiring Harness . . . . .	6-4
Disassembly and Assembly . . . . .	6-6
Removal and Installation . . . . .	6-5
<b>BATTERY</b>	
Checking the Battery . . . . .	6-2
Removal and Installation . . . . .	6-2
<b>ELECTRICAL SYSTEM INFORMATION</b>	
Description . . . . .	6-1
<b>MANDO ALTERNATOR</b>	
Disassembly and Assembly . . . . .	6-9
Removal and Installation . . . . .	6-8
<b>STARTER</b>	
Checking the Starter . . . . .	6-12
Disassembly and Assembly . . . . .	6-14
Removal and Installation . . . . .	6-12
Replacing the Brushes . . . . .	6-15
<b>TROUBLESHOOTING</b>	
Chart . . . . .	6-1

**ELECTRICAL  
SYSTEM**

**MELROE** *COMPANY*




**A BUSINESS UNIT OF CLARK EQUIPMENT COMPANY**

# WIRING DIAGRAM (P/N 6722195)

## BUCKET POSITION VALVE LOCKOUT (OPTIONAL)

### Model 753, 7753, 843, 843B & 853

(Printed April 1992)



MC-1450  
MC-1118

### WIRE LEGEND

WIRE NO.	COLOR	CONNECTS TO
12S-A	Orange	Loader Wiring Harness Fused & Switched Power
12S-B	Orange	Switch
59E-A	Orange	Switch
59E-B	Orange	Switch
50-A	Black	Solenoid
50-B	Black	Solenoid Ground

### PARTS LEGEND

- ① Switch Cover
- ② Switch
- ③ Solenoid
- ④ Terminal
- ⑤ Connector
- ⑥ Bucket Position Valve
- ⑦ Wiring Harness




# WIRING DIAGRAM (P/N 6570239)

## 843 (S/N 12999 & Below)

(Printed December 1985)

### CAB HARNESS




# CAB HARNESS

## WIRE LEGEND

## PARTS LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1	Black	16	34	Dk. Blue	16
2	Black	16	35	Black	16
3	Orange	16	36	Black	16
4	Orange	12	37	Black	16
5	Orange/White	16	38	Brown	16
6	White	16	39	Black	16
7	Lt. Blue	16	40	Brown	16
8	Orange/Green	16	41	Yellow	16
9	Yellow/Black	18	42	Purple	16
10	Yellow	18	43	White	16
11	White/Purple	18	44	Lt. Blue	16
12	Purple	18	45	Red	16
13	Lt. Blue/Black	16	46	Orange (Not Used)	16
14	Yellow	18	47	Grey (Not Used)	16
15	Purple	18	48	Brown (Not Used)	16
16	Orange	16	49	Black	16
17	Orange	16			
18	White/Orange	16			
19	Orange/Dk. Blue	16			
20	Orange	18			
21	Black	16			
22	Orange	18			
23	Orange	18			
24	Dk. Green/Yellow	16			
25	Orange	18			
26	Black	16			
27	Orange/Black	16			
28	Orange/Black	16			
29	Orange/Dk. Blue	16			
30	Orange/Dk. Blue	16			
31	White/Dk. Blue	16			
32	Pink	16			
33	Brown	16			

1	Harness Connectors	21	Fuse - Ignition
2	Operator Cab Ground	22	Ignition Switch
3	Fuel Sender	23	Glow Plug Indicator (543 Only)
4	Back-Up Alarm (Opt.)	24	Shut-Down Module (Opt.)
5	Rear Lamp		
6	Tail Lamp	●	Tee splice
7	Left Flasher Lamp (Opt.)	○	Butt splice
8	Left Front Lamp		
9	Wiper Motor (Opt.)		
10	Flasher (Opt.)		
11	Right Front Lamp		
12	Right Flasher Lamp (Opt.)		
13	Hourmeter		
14	Light Switch		
15	Fuse - Accessory		
16	Wiper Switch (Opt.)		
17	Fuel Gauge		
18	Trans. Warning Light		
19	Engine Warning Light		
20	Voltmeter		



**ENGINE HARNESS**



# ENGINE HARNESS


WIRE LEGEND		PARTS LEGEND	
NO.'s	COLOR GAUGE	1	18
1	Black 16	Harness Connectors	Frame Ground
2	Black 16	2	19
3	White/Orange 16	Unfused & Live Accessories	Diode
4	Orange 12	3	
5	White/Green 16	Fuse and Live Accessories	
6	White/Black 16	4	
7	Orange/Green 16	Engine Connector	
8	Yellow/Black 16	5	
9	Yellow 16	Back-Up Alarm Switch (Opt.)	
10	Purple 16	6	
11	Lt. Blue/Black 16	Trans. Oil Temperature	
12	Orange 12	7	
13	White/Lt. Green 16	Trans. Charge Pressure	
14	White 12	8	
15	Lt. Green 16	Brake Switch	
16	Orange 12	9	
17	Orange 12	Starter	
18	White/Orange 16	10	
19	White/Green 16	Engine Oil Pressure	
20	Lt. Blue/Orange 8	11	
21	Red Cable	Fuel Shut-Off Solenoid	
22	Black Cable	12	
23	Red Cable	Thermo-Start or Glow Plug	
24	Red Cable	13	
25	Black Cable	Engine Coolant Temperature	
		14	
		Alternator	
		15	
		Batteries	
		16	
		Pre-Heat Relay	
		17	
		Start Relay	

# WIRING DIAGRAM (P/N 6566813)

## 843 (S/N 13001 Thru 19999)

(Printed December 1985)

**CAB HARNESS**




# CAB HARNESS

## WIRE LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	41	Pink	16
1F	Red	16	42FL	Dk. Blue	16
10A	Black	12	42FR	Dk. Blue	16
10B	Black	12	42R	Dk. Blue/White	16
12	Orange	16	46	Brown	16
12A	Orange	18	46L	Brown	16
12B	Orange	16	46R	Brown	16
12C	Orange	16	49F	Gray	16
12F	Orange	18	49T	Gray	16
12L	Orange	18	49V	Gray	16
12T	Orange	18	60W	Black	16
19C	Red/White	16	63	Orange/Black	16
19F	Red/White	16	66	Orange/Green	16
19H	Red/White	18			
19L	Red/White	16			
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
28	Lt. Blue/Black	16			
30	Black	16			
30F	Black	16			
30G	Black	16			
30T	Black	16			
31P	Yellow/Green	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			
36T	Purple/White	18			
40FL	Black	16			
40FR	Black	16			
40R	Black	16			

## PARTS LEGEND

NO.	DESCRIPTION	NO.	DESCRIPTION
1	Harness Connectors	21	Voltmeter
2	Operator Cab Ground	22	Ignition Switch
3	Fuel Sender	23	Hourmeter
4	Back-Up Alarm (Opt.)		
5	Rear Lamp		● Tee splice
6	Tail Lamp		○ Butt splice
7	Left Flasher Lamp (Opt.)		
8	Left Front Lamp		
9	Wiper (Opt.)		
10	Flasher (Opt.)		
11	Right Front Lamp		
12	Right Flasher Lamp (Opt.)		
13	Engine Temperature Gauge		
14	Fuel Gauge		
15	Light Switch		
16	Wiper Switch (Opt.)		
17	Trans. Warning Light		
18	Engine Warning Light		
19	Fuse - Ignition		
20	Fuse - Accessory		



**ENGINE HARNESS**

# ENGINE HARNESS

## WIRE LEGEND

NO.'s	COLOR	GAUGE
0	Black	Cable
1	Red	Cable
1A	Red	8
1B	Red	12
1C	Red	12
1D	Red	12
10A	Black	12
12C	White/Orange	16
14F	Lt. Green	16
14R	Lt. Green/White	16
21R	White	16
21S	White/Green	12
23F	White/Black	16
28	Lt. Blue/Black	16
28B	Lt. Blue/Orange	8
28S	Lt. Blue/Yellow	16
31P	Yellow/Lt. Green	16
32F	Yellow/Dk. Blue	16
32PT	Yellow	16
32T	Yellow/Black	16
35H	Yellow/Brown	16
36T	Purple/White	16
60B	Black	16
66	Orange/Green	16

## PARTS LEGEND


①	Harness Connectors	⑰	Start Relay
②	Unfused & Live Accessories	⑱	Frame Ground
③	Engine Connector	⑲	Engine Ground
④	Back-Up Alarm Switch (Opt.)		
⑤	Trans. Oil Temperature Switch		
⑥	Trans. Charge Pressure Switch		
⑦	Starter		
⑧	Engine Oil Pressure Switch		
⑨	Fuel Shut-Off Solenoid (Internal)		
⑩	Hydraulic Fluid Filter Pressure Switch		
⑪	Glow Plugs		
⑫	Engine Coolant Temp. Sender		
⑬	Diode		
⑭	Alternator		
⑮	Batteries		
⑯	Pre-Heat Relay		

# WIRING DIAGRAM (P/N 6570240)

## 843 (S/N 20001 Thru 23999)

(Printed July 1988)

**CAB HARNESS**




# CAB HARNESS

## WIRE LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	40FL	Black	16
1F	Red	16	40FR	Black	16
10A	Black	12	40R	Black	16
10B	Black	12	41	Pink	16
12	Orange	16	42FL	Dk. Blue	16
12A	Orange	18	42FR	Dk. Blue	16
12B	Orange	12	42R	Dk. Blue/White	16
12C	Orange	16	46	Brown	16
12F	Orange	18	46L	Brown	16
12L	Orange	18	46R	Brown	16
12T	Orange	18	49F	Gray	16
19C	Red/White	16	49T	Gray	16
19F	Red/White	16	49V	Gray	16
19H	Red/White	18	60W	Black	16
19L	Red/White	16	66	Orange/Green	16
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
21RM	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
28	Lt. Blue/Black	16			
30	Black	16			
30F	Black	16			
30G	Black	16			
30T	Black	16			
31FP	Yellow	16			
31P	Yellow/Green	18			
32FPT	Yellow	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			
36T	Purple/White	18			

## PARTS LEGEND

①	Harness Connectors	②①	Fuse - Accessory
②	Operator Cab Ground	②②	Voltmeter
③	Fuel Sender	②③	Ignition Switch
④	Back-Up Alarm (Opt.)	②④	Hourmeter
⑤	Rear Lamp		● Tee splice
⑥	Tail Lamp		○ Butt splice
⑦	Left Flasher Lamp (Opt.)		
⑧	Left Front Lamp		
⑨	Wiper (Opt.)		
⑩	Wiper Switch (Opt.)		
⑪	Shut Down Module (Opt.)		
⑫	Flasher (Opt.)		
⑬	Right Front Lamp		
⑭	Right Flasher Lamp (Opt.)		
⑮	Engine Temperature Gauge		
⑯	Fuel Gauge		
⑰	Light Switch		
⑱	Trans. Warning Light		
⑲	Engine Warning Light		
⑳	Fuse - Ignition		



**ENGINE HARNESS**




# ENGINE HARNESS

WIRE LEGEND		PARTS LEGEND	
NO.'s	COLOR	GAUGE	
0	Black	Cable	① Harness Connectors
1	Red	Cable	② Back-Up Alarm Switch (Opt.)
1A	Red	12	③ Trans. Fluid Temp. Switch
1B	Red	10	
1C	Red	12	④ Trans. Charge Pressure Switch
1D	Red	12	
10A	Black	12	⑤ Starter
12C	White/Orange	16	
14F	Lt. Green	16	⑥ Injection Pump Shut-Off
14R	Lt. Green/White	16	⑦ Hydrostatic Filter Switch
21R	White	16	⑧ Engine Oil Press. Switch
21S	White/Green	12	⑨ Engine Coolant Temp. Sender
23F	White/Black	16	⑩ Engine Glow Plugs
28	Lt. Blue/Black	16	⑪ Diode
28B	Lt. Blue/Orange	8	⑫ Alternator
28S	Lt. Blue/Yellow	16	⑬ Battery
31P	Yellow/Lt. Green	16	⑭ Start Relay
32F	Yellow/Dk. Blue	16	⑮ Pre-Heat Relay
32P	Yellow	16	⑯ Harness Connectors
32T	Yellow/Black	16	
35H	Yellow/Brown	16	
36T	Purple/White	16	
60B	Black	16	
66	Orange/Green	16	

# WIRING DIAGRAM (P/N 6570913)

## 843 (S/N 24001 Thru 25999)


(Printed July 1988)



\* Wire 26LT is connected to wire 26 when module is not used.

CAB HARNESS





E-1821

**ENGINE HARNESS**

# ENGINE HARNESS

## WIRE LEGEND

NO.'s	COLOR	GAUGE
0	Black	Cable
1	Red	Cable
1A	Red	8
1B	Red	10
1C	Red	12
1D	Red	12
10A	Black	12
12C	White/Orange	16
14F	Lt. Green	16
14R	Lt. Green/White	16
21R	White	16
21S	White/Green	12
23F	White/Black	16
28	Lt. Blue/Black	16
28B	Lt. Blue/Orange	8
28S	Lt. Blue/Yellow	16
31P	Yellow/Lt. Green	16
32F	Yellow/Dk. Blue	16
32PT	Yellow	16
32T	Yellow/Black	16
35H	Yellow/Brown	16
36T	Purple/White	16
60B	Black	16
66	Orange/Green	16


## PARTS LEGEND

1	Harness Connectors	17	Start Relay
2	Unfused & Live Accessories	18	Frame Ground
3	Engine Connector	19	Engine Ground
4	Back-Up Alarm Switch (Opt.)		
5	Trans. Oil Temperature Switch		
6	Trans. Charge Pressure Switch		
7	Starter		
8	Engine Oil Pressure Switch		
9	Fuel Shut-Off Solenoid (Internal)		
10	Hydraulic Fluid Filter Pressure Switch		
11	Glow Plugs		
12	Engine Coolant Temp. Sender		
13	Diode		
14	Alternator		
15	Battery		
16	Pre-Heat Relay		

# WIRING DIAGRAM (P/N 6570914)

843 (S/N 26001 Thru 28134)

(Printed July 1988)



CAB HARNESS

\* Wire 26LT is connected to wire 26 when module is not used.

# CAB HARNESS


## WIRE LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	40FL	Black	16
1F	Red	16	40FR	Black	16
10A	Black	12	40R	Black	16
10B	Black	12	41	Pink	16
12	Orange	16	42FL	Dk. Blue	16
12A	Orange	18	42FR	Dk. Blue	16
12B	Orange	12	42R	Dk. Blue/White	16
12C	Orange	16	46	Brown	16
12F	Orange	18	46L	Brown	16
12L	Orange	18	46R	Brown	16
12T	Orange	18	49F	Gray	16
19C	Red/White	16	49T	Gray	16
19F	Red/White	16	49V	Gray	16
19H	Red/White	18	60W	Black	16
19L	Red/White	16	66	Orange/Green	16
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
21RM	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
28	Lt. Blue/Black	16			
30	Black	16			
30F	Black	16			
30G	Black	16			
30T	Black	16			
31FP	Yellow	16			
31P	Yellow/Green	18			
32FPT	Yellow	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			
36T	Purple/White	18			

## PARTS LEGEND

①	Harness Connectors	②①	Fuse - Accessory
②	Operator Cab Ground	②②	Voltmeter
③	Fuel Sender	②③	Ignition Switch
④	Back-Up Alarm (Opt.)	②④	Hourmeter
⑤	Rear Lamp	●	Tee splice
⑥	Tail Lamp	○	Butt splice
⑦	Left Flasher Lamp (Opt.)		
⑧	Left Front Lamp		
⑨	Wiper (Opt.)		
⑩	Wiper Switch (Opt.)		
⑪	Shut Down Module (Opt.)		
⑫	Flasher (Opt.)		
⑬	Right Front Lamp		
⑭	Right Flasher Lamp (Opt.)		
⑮	Engine Temperature Gauge		
⑯	Fuel Gauge		
⑰	Light Switch		
⑱	Trans. Warning Light		
⑲	Engine Warning Light		
⑳	Fuse - Ignition		

\*Wire 26LT is connected to wire 26 when module is not used.



ENGINE HARNESS

E-1820



# ENGINE HARNESS

## WIRE LEGEND

## PARTS LEGEND

NO.'s	COLOR	GAUGE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
0	Black	Cable	Harness Connectors	Start Relay																	
1	Red	Cable	Unfused & Live Accessories	Frame Ground																	
1A	Red	8	Engine Connector	Engine Ground																	
1B	Red	10	Back-Up Alarm Switchs (Opt.)																		
1C	Red	12	Trans. Oil Temperature Switch																		
1D	Red	12	Trans. Charge Pressure Switch																		
10A	Black	16	Starter																		
12C	White/Orange	16	Engine Oil Pressure Switch																		
14F	Lt. Green	16	Fuel Shut-Off Solenoid (internal)																		
14R	Lt. Green/White	16	Hydraulic Fluid Filter Pressure Switch																		
21R	White	16	Glow Plugs																		
21S	White/Green	12	Engine Coolant Temp. Sender																		
23F	White/Black	16	Diode																		
28	Lt. Blue/Black	16	Alternator																		
28B	Lt. Blue/Orange	8	Battery																		
28S	Lt. Blue/Yellow	16	Pre-Heat Relay																		
31P	Yellow/Lt. Green	16																			
32F	Yellow/Dk. Blue	16																			
32PT	Yellow	16																			
32T	Yellow/Black	16																			
35H	Yellow/Brown	16																			
36T	Purple/White	16																			
60BA	Black	16																			
60B	Black	16																			
66	Orange/Green	16																			

# CAB HARNESS


## WIRE LEGEND

## PARTS LEGEND

# WIRING DIAGRAM (P/N 6570915)

843 (S/N 28135 & Above) & 843B

(Printed September 1990)



\* Wire 26A is connected to wire 26 when module is not used.

CAB HARNESS


# CAB HARNESS

## WIRE LEGEND


NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	36T	Purple/White	18
1F	Red	16	40R	Black	16
10A	Black	12	40FL	Black	16
10B	Black	14	40FR	Black	16
10AB	Black	12	41	Pink	16
12A	Orange	18	42FL	Dk. Blue	16
12B	Orange	16	42FR	Dk. Blue	16
12C	Orange	16	42R	Dk. Blue/White	16
12F	Orange	16	46	Brown	16
12L	Orange	18	46L	Brown	16
12T	Orange	18	46R	Brown	16
12V	Orange	18	49F	Gray	18
19C	Red/White	16	49T	Gray	18
19F	Red/White	16	49V	Gray	18
19H	Red/White	18	60W	Black	16
19L	Red/White	16	66	Orange/Green	16
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
21RM	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
26A	Lt. Blue	16			
28	Lt. Blue/Black	16			
30.	Black	16			
30G	Black	16			
30T	Black	16			
31	Yellow	18			
31P	Yellow/Green	18			
32	Yellow	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			

## PARTS LEGEND

①	Harness Connectors	⑱	Fuel Gauge
②	Ground	⑳	Hourmeter
③	Fuel Sender	㉑	Fuse (Ignition)
④	Back-Up Alarm (Opt. 843B Only)	㉒	Fuse (Accessory)
⑤	Rear Light (Opt. 843B Only)	㉓	Light Switch (Opt. 843 Only)
⑥	Tail Light (Opt. 843B Only)	㉔	Ignition Switch
⑦	Left Flasher Light (Opt.)		
⑧	Left Front Light (Opt. 843B Only)		
⑨	Wiper Switch (Opt.)		
⑩	Wiper (Opt.)		
⑪	Shut Down Module (Opt.)		
⑫	Flasher (Opt.)		
⑬	Right Front Light (Opt. 843B Only)		
⑭	Right Flasher Light (Opt.)		
⑮	Trans. Warning Light		
⑯	Engine Warning Light		
⑰	Voltmeter		
⑱	Temperature Gauge		



..... wire 26  
when module is not used.



# ENGINE HARNESS

E-1820



## 6 ELECTRICAL SYSTEM

### ELECTRICAL SYSTEM INFORMATION

#### Description

The loader has a 12 volt, negative ground electrical system. There are two main circuits.

1. The charging circuit has an alternator (with built-in regulator), a voltmeter and a battery.
2. The starting circuit has a starter motor, solenoids and other components for starting the engine.

The loader also has front and rear lights. Optional windshield wiper, horn and back-up alarm.


The electrical system is protected by two fuses installed in the instrument panel. Fuses protect the electrical system from an overload.

#### TROUBLESHOOTING

The following troubleshooting chart is provided as an assistance in locating and correcting problems which are most common. Many of the recommended procedures must be done by authorized Bobcat Service Personnel only.

PROBLEM	CAUSE
Battery does not charge.	1, 2, 3, 4, 5
Alternator will not charge.	1, 2, 5
Starter will not turn the engine.	2, 3, 4, 6, 7, 8, 9

KEY TO CORRECT THE CAUSE
<ol style="list-style-type: none"><li>1. Alternator belt is loose or damaged.</li><li>2. Battery connections are dirty or loose.</li><li>3. Battery is damaged.</li><li>4. The ground connection is not making a good contact.</li><li>5. The alternator is damaged.</li><li>6. The engine is locked.</li><li>7. The starter is damaged.</li><li>8. The wiring or the solenoid is damaged.</li><li>9. Check the fuses.</li></ol>



## WARNING

Instructions are necessary before operating or servicing machine. Read Operator's Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1285

## BATTERY


### Checking the Battery

The tool listed will be needed to do the following procedure:

MEL-10004 – Battery Tester

To make a safe and complete check of the battery see the Clark Battery Manual (P/N 6566047).

The Battery Manual has all the information and specifications needed for checking and servicing the battery. Replace the battery as needed.




**⚠ WARNING**

Batteries contain acid which burns eyes or skin on contact. Wear goggles and protective clothing and rubber gloves to keep acid off body.

In case of acid contact, wash immediately with water for several minutes and get medical attention.

W-2065-1285




**DO NOT** remove the vent caps from the battery while charging the battery. The battery has vent caps which will decrease the possibility of the battery being exploded by an external spark.

### Removal and Installation

Disconnect the battery cables. Always remove the negative (-) cable first to prevent sparks **A**.

Remove the nuts and bolts from the holddown clamp and remove the holddown clamp **B**.

Remove the battery from the loader **C**.




## ALTERNATOR

### Alternator Belt Adjustment


Open the rear door.

Remove the bolts from the belt shield.

Remove the belt shield from the engine **A**.




Loosen the adjustment bolt **B**.



Move the alternator to set the belt tension at 1/4" (6,5 mm) deflection with 5 lbs. pressure **C**.

Tighten the adjustment bolt **B**.

Install the belt shield.





## ALTERNATOR (Cont'd)

### Checking the Alternator Wire Harness


Turn the key switch to the "ON" position and make the checks as follows **A**.

Connect a voltmeter between ground and No. 1 terminal.

Connect a voltmeter between ground and No. 2 terminal.

Connect a voltmeter between ground and "BAT" terminal.


If any of the tests show zero voltage, the wiring harness has a defect. Repair the wiring harness as needed.



### Checking Alternator Output

Lift and block the loader (See Page 1-2 for the correct procedure).

Disconnect the "BAT" terminal at the alternator **B**.




Connect the "BAT" wire to one side of the ammeter. Connect the other side to the "BAT" terminal of the alternator **C**.

Disconnect the fuel shut-off wire at the injection pump. Turn the engine, with the starter for 30 seconds to lower the charge in the battery.

Connect the fuel shut-off wire.

Start the engine and run at full RPM.

The ammeter reading must be within 10% of rated amperage (37 amps. @ 2100 RPM) **C**.




### Checking Alternator Regulator

Use the same procedure as above for "Checking Alternator Output" except for the following:

Put a small screwdriver in the test hole **D**.

The ammeter reading must be within 10% of rated amperage (37 amps. @ 2100 RPM).

If the reading is less than 10% of rated amperage, check the diode trio, rectifier, stator or rotor.




**ALTERNATOR (Cont'd)**

**Removal and Installation**


Remove the belt shield at the engine.

Disconnect the negative (-) cable at the battery.


Disconnect the wire at the "BAT" terminal **A**.



Disconnect the No. 1 & 2 terminals **B**.





Remove the adjustment bolt **C**.



Remove the mounting bolt **D**.

Remove the alternator from the engine.





**ALTERNATOR (Cont'd)**


**Disassembly and Assembly**

Disassemble the alternator as shown **A**.

Connect an ohmmeter as follows to check the rotor **B**.

Between one slip ring and the shaft. Check the other slip ring. There must be maximum resistance.

Between both slip rings. There must be 2.4 to 3.0 ohms resistance.




Connect a battery powered test light as follows to check the stator **C**.

Between the center wire and an outside wire. Light must come "ON".

Between center wire and the other outside wire. Light must come "ON".

Between one of the wires and frame. Light must NOT come "ON".



## ALTERNATOR (Cont'd)

Connect a D.C. test light as follows to check the diode trio [A].

### IMPORTANT

Do not use voltage which is more than circuit voltage to check the diode trio or the rectifier on the alternator.

I-2026-0284

Between a single connection and one of the three connections. Connect the tester in the opposite direction. The light must come "ON" in one direction, but not in the other direction.

Check each diode with the same procedure.

Connect a test light as follows to check the rectifier [B].

Between one connection and insulated heat sink. Connect the test light in opposite direction. The light must come "ON" in one direction, but not in the other direction.





Between one connection and the grounded heat sink. Connect test light in opposite direction. The light must come "ON" in one direction, but not in the other direction.

Assembly: Reverse the order of disassembly.

Also if regulator was removed, install new insulated washers and spacers [C].


When installing the brushes, put a piece of straight wire through the housing to hold the brushes in the up position [D].

Then install the rotor, when in position pull the wire out to seat the brushes.



## MELROE ALTERNATOR

### Checking the Alternator Output



Lift and block the loader (Refer to Page 1-2 for the correct procedure).

Disconnect the negative (-) cable from the battery.

Remove the belt shield.

Connect the orange lead (Item 1) from the alternator output terminal to the negative (-) side of the ammeter. Connect the positive (+) side of the ammeter to the output terminal on the alternator (Item 2) **A**.

Disconnect the fuel shut-off wire.

Connect the negative (-) cable to the battery.

Turn on the lights and crank the engine for 30 seconds to run the battery down.



Connect the fuel shut-off wire.

Start the engine and run at 2600 R.P.M.

The ammeter reading should be between 45 & 55 amps. @ 2600 RPM.



If the reading is low, disconnect the battery and connect a jumper wire from the alternator output terminal (Item 1) to the regulator terminal (Item 2).

Connect the battery cable, start the engine and check the ammeter. If the reading is within the rated amperage (45-55 amps. @ 2600 RPM) replace the diode trio **B**.



### Checking the Alternator Regulator

Connect the positive (+) voltmeter lead to the positive (+) battery terminal and connect the negative (-) voltmeter lead to the negative (-) battery terminal **A**.



Start and run the engine at 1500 - 2000 R.P.M. The voltmeter should be between 13.9 - 14.7 volts **A**.



If the reading is low, stop the engine and disconnect the battery.

Remove the screws and pull the regulator cover away from the alternator. Connect the jumper wire from the ground stud (Item 1) to the brush terminal (Item 2) (the tan wire) **B**.

Connect the battery and start the engine. Run at 1500 RPM. DO NOT allow the meter to exceed 16 volts.

If the reading is 14.5 or above, replace the regulator.

If the reading is 14.5 or below, repair or replace the alternator.




## MELROE ALTERNATOR (Cont'd)

### Removal and Installation

Disconnect the negative cable from battery.


Disconnect the wire terminals from the back of the alternator **A**.




Disconnect the battery terminal **B**.

Remove the adjustment bolt and the mounting bracket bolt.


Remove the alternator.



	<b>WARNING</b>
<b>AVOID INJURY</b>	
Never service or adjust the machine when the engine is running unless instructed to do so in the manual.	
W-2012-1285	

**A**

1. Nut
2. Pulley
3. Fan
4. Bolt
5. Case Half (Front)
6. Bearing
7. Rotor
8. Slip Ring
9. Stator
10. Heat Sink (+)
11. Heat Sink (-)
12. Case Half (Rear)
13. Condenser Assy.
14. Brush Holder Kit
15. Regulator Kit



D-1760

**MELROE ALTERNATOR (Cont'd)****Disassembly and Assembly**

Disassemble the alternator as shown **A**.

Remove three (3) bolts (Item 4) holding halves together.

Pry halves apart.

Use a soft jaw vise to hold rotor while removing pulley nut (Item 1).


Remove front case half (Item 5) from the rotor using a plastic hammer or press.

Unsolder the stator wires from the rectifier to test the stator and rectifier. Use a needle nose plier to aid in removal of the wires.


Use the following procedure with an ohmmeter to test the rotor:

Touch both probes on the slip rings. There must be a 3 to 5 ohm reading **B**.

Touch one probe to the shaft and one probe to a slip ring, then to the other. There must be maximum resistance **C**.

**B**

B-9375

**C**


B-9376




### MELROE ALTERNATOR (Cont'd)

Use the following procedure with an ohmmeter to test the stator:

Touch to (2) bare wires of the stator with the probes, take a reading. Move one probe to the other wire. The readings should be the same **A**.




Test for ground by touching one probe on the metal surface of the stator and the other probe on the bare wire. There must be no needle movement **B**.




Use the following procedure with a circuit tester to test the rectifier:

Touch the positive probe to the positive diode holder and the negative probe to each diode terminal. There must be continuity **C**.




Reverse the probes and check the other direction. There must be no continuity **D**.



**MANDO ALTERNATOR (Cont'd)**


Touch the negative probe to the negative diode holder and the positive probe to each diode terminal. There must be continuity **A**.



Reverse the probe and check the other direction. There must be no continuity **B**.


Check the brushes for wear. The maximum length of exposed brushes should be .125" (3 mm).

Replace broken or rusted brush springs.



Reverse the order of disassembly.

Place the rotor in soft jaws when tightening the shaft nut. Tighten to 50 ft.-lbs. (70 Nm) torque **C**.



## STARTER

### Checking the Starter

The key switch must be in the "OFF" position.

The battery must be at full charge.

The cable connections must be clean and tight.

Connect a jumper wire between "S" terminal and "BAT" terminal **A**.

If the starter turns but does not turn the engine, the starter drive has a defect.

Connect a jumper wire between the "M" terminal and the "BAT" terminal **B**.

If the starter turns, the defect is in the solenoid.





If the starter does not turn, the starter is defective.

### Removal and Installation

Disconnect the negative (-) cable at the battery.


Disconnect the wire at the "BAT" terminal of the solenoid **C**.

Disconnect the wires at the solenoid **D**.




**STARTER (Cont'd)**


Remove the bolts at the starter bracket **A**.




Remove the starter mounting bolts **B**.



Remove the starter from the engine **C**.





### STARTER (Cont'd)

#### Disassembly and Assembly



Disassemble the starter as shown **A**.

## WARNING

Wear safety glasses to prevent eye injury when any of the following conditions exist:

- When fluids are under pressure.
- Flying debris or loose material is present.
- Engine is running.
- Tools are being used.

W-2019-1285



#### Cleaning and Inspection

Use a brush and air pressure to clean the drive, field coils, armature and starter housing.

**NOTE:** Do not use solvent to clean the drive assembly. The solvent will remove the lubricant and the drive will slip.

## STARTER (Cont'd)

Check the following items:

### Armature

To check the armature for grounds, place one probe from the ammeter on the iron core and one probe on the commutator. The test lamp should not light Page 6-14 **A**.

To check for open circuit, place the armature on a growler as shown. Place a hacksaw blade on the armature. If the hacksaw blade vibrates while the armature rotates, the winding is short circuited and must be replaced Page 6-14 **B**.

Also check:

- Broken or burned insulation
- Loose connections at commutator
- Worn shaft or bearings
- Rough commutator

### Brush Holders

- Brush springs
- Broken insulation
- Spring tension

### Field Coils

To test for a continuity, disconnect the field winding ground connections. Touch one probe to the field connector and one probe to the brush. The lamp should not light **A**.

To test for ground, touch one probe to the body and the other probe to the field windings end of the brush. The lamp should not light **B**.

Also check:

- Broken or burned insulation
- Brush connections
- Brushes

### Drive Gear

- Worn teeth
- Tooth engagement (Drive gear must engage ring gear by 1/2 the depth of ring gear teeth)

### Replacing the Brushes

Remove the brush screw and remove the brush. Replace the brush wire by screws or by cutting the old wire. Solder the new brush wire to the ends of the old wire, or screw the wire in place.

Assembly: Reverse the order of disassembly.

Put a small amount of grease on the splines of the armature and the bushings.

