


Copyright © 1997 by Melroe Corporation. All rights reserved. MELROE is a registered trademark of Melroe Corporation.

ELECTRICAL SYSTEM

	Page Number
ALTERNATOR	
Alternator Belt Adjustment	6-3
Checking Alternator Output	6-4
Checking Alternator Regulator	6-4
Checking Alternator Wiring Harness	6-4
Disassembly and Assembly	6-6
Removal and Installation	6-5
BATTERY	
Checking the Battery	6-2
Removal and Installation	6-2
ELECTRICAL SYSTEM INFORMATION	
Description	6-1
MANDO ALTERNATOR	
Disassembly and Assembly	6-9
Removal and Installation	6-8
STARTER	
Checking the Starter	6-12
Disassembly and Assembly	6-14
Removal and Installation	6-12
Replacing the Brushes	6-15
TROUBLESHOOTING	
Chart	6-1



MELROE *COMPANY*




A BUSINESS UNIT OF CLARK EQUIPMENT COMPANY

WIRING DIAGRAM (P/N 6722195)

BUCKET POSITION VALVE LOCKOUT (OPTIONAL)

Model 753, 7753, 843, 843B & 853

(Printed April 1992)



MC-1450
MC-1118

WIRE LEGEND

WIRE NO.	COLOR	CONNECTS TO
12S-A	Orange	Loader Wiring Harness Fused & Switched Power
12S-B	Orange	Switch
59E-A	Orange	Switch
59E-B	Orange	Solenoid
50-A	Black	Solenoid
50-B	Black	Ground

PARTS LEGEND


- ① Switch Cover
- ② Switch
- ③ Solenoid
- ④ Terminal
- ⑤ Connector
- ⑥ Bucket Position Valve
- ⑦ Wiring Harness


WIRING DIAGRAM (P/N 6570239)

843 (S/N 12999 & Below)

(Printed December 1985)

CAB HARNESS






ENGINE HARNESS


WIRING DIAGRAM (P/N 6566813)

843 (S/N 13001 Thru 19999)

(Printed December 1985)

CAB HARNESS





ENGINE HARNESS

ENGINE HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE
0	Black	Cable
1	Red	Cable
1A	Red	8
1B	Red	12
1C	Red	12
1D	Red	12
10A	Black	12
12C	White/Orange	16
14F	Lt. Green	16
14R	Lt. Green/White	16
21R	White	16
21S	White/Green	12
23F	White/Black	16
28	Lt. Blue/Black	16
28B	Lt. Blue/Orange	8
28S	Lt. Blue/Yellow	16
31P	Yellow/Lt. Green	16
32F	Yellow/Dk. Blue	16
32PT	Yellow	16
32T	Yellow/Black	16
35H	Yellow/Brown	16
36T	Purple/White	16
60B	Black	16
66	Orange/Green	16

PARTS LEGEND


1	Harness Connectors	17	Start Relay
2	Unfused & Live Accessories	18	Frame Ground
3	Engine Connector	19	Engine Ground
4	Back-Up Alarm Switch (Opt.)		
5	Trans. Oil Temperature Switch		
6	Trans. Charge Pressure Switch		
7	Starter		
8	Engine Oil Pressure Switch		
9	Fuel Shut-Off Solenoid (Internal)		
10	Hydraulic Fluid Filter Pressure Switch		
11	Glow Plugs		
12	Engine Coolant Temp. Sender		
13	Diode		
14	Alternator		
15	Batteries		
16	Pre-Heat Relay		

WIRING DIAGRAM (P/N 6570240)

843 (S/N 20001 Thru 23999)

(Printed July 1988)

CAB HARNESS



6570240 (7-88)

Printed in U.S.A.

CAB HARNESS

WIRE LEGEND

PARTS LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE	①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰	⑱	⑳	
1D	Red	12	40FL	Black	16	Harness Connectors	Operator Cab Ground	Fuel Sender	Back-Up Alarm (Opt.)	Rear Lamp	Tail Lamp	Left Flasher Lamp (Opt.)	Left Front Lamp	Wiper (Opt.)	Wiper Switch (Opt.)	Shut Down Module (Opt.)	Flasher (Opt.)	Right Front Lamp	Right Flasher Lamp (Opt.)	Engine Temperature Gauge	Fuel Gauge	Light Switch	Trans. Warning Light	Engine Warning Light	Fuse - Ignition
1F	Red	16	40FR	Black	16																				
10A	Black	12	40R	Black	16																				
10B	Black	12	41	Pink	16																				
12	Orange	16	42FL	Dk. Blue	16																				
12A	Orange	18	42FR	Dk. Blue	16																				
12B	Orange	12	42R	Dk. Blue/White	16																				
12C	Orange	16	46	Brown	16																				
12F	Orange	18	46L	Brown	16																				
12L	Orange	18	46R	Brown	16																				
12T	Orange	18	49F	Gray	16																				
19C	Red/White	16	49T	Gray	16																				
19F	Red/White	16	49V	Gray	16																				
19H	Red/White	18	60W	Black	16																				
19L	Red/White	16	66	Orange/Green	16																				
19S	Red/White	16																							
19W	Red/White	16																							
21R	White	16																							
21RM	White	16																							
23F	White/Black	16																							
26	Lt. Blue	16																							
28	Lt. Blue/Black	16																							
30	Black	16																							
30F	Black	16																							
30G	Black	16																							
30T	Black	16																							
31FP	Yellow	16																							
31P	Yellow/Green	16																							
32FPT	Yellow	18																							
32PT	Yellow	18																							
35H	Yellow/Brown	18																							
36	Purple	16																							
36T	Purple/White	18																							

● Tee splice

○ Butt splice

ENGINE HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE
0	Black	Cable
1	Red	Cable
1A	Red	12
1B	Red	10
1C	Red	12
1D	Red	12
10A	Black	12
12C	White/Orange	16
14F	Lt. Green	16
14R	Lt. Green/White	16
21R	White	16
21S	White/Green	12
23F	White/Black	16
28	Lt. Blue/Black	16
28B	Lt. Blue/Orange	8
28S	Lt. Blue/Yellow	16
31P	Yellow/Lt. Green	16
32F	Yellow/Dk. Blue	16
32P	Yellow	16
32T	Yellow/Black	16
35H	Yellow/Brown	16
36T	Purple/White	16
60B	Black	16
66	Orange/Green	16


PARTS LEGEND

①	Harness Connectors
②	Back-Up Alarm Switch (Opt.)
③	Trans. Fluid Temp. Switch
④	Trans. Charge Pressure Switch
⑤	Starter
⑥	Injection Pump Shut-Off
⑦	Hydrostatic Filter Switch
⑧	Engine Oil Press. Switch
⑨	Engine Coolant Temp. Sender
⑩	Engine Glow Plugs
⑪	Diode
⑫	Alternator
⑬	Battery
⑭	Start Relay
⑮	Pre-Heat Relay
⑯	Harness Connectors

WIRING DIAGRAM (P/N 6570913)

843 (S/N 24001 Thru 25999)

(Printed July 1988)



* Wire 26LT is connected to wire 26 when module is not used.

CAB HARNESS

6570913 (7-88)

CAB HARNESS

WIRE LEGEND

PARTS LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
1D	Red	12	40FL	Black	16	Harness Connectors	Operator Cab Ground	Fuel Sender	Back-Up Alarm (Opt.)	Rear Lamp	Tail Lamp	Left Flasher Lamp (Opt.)	Left Front Lamp	Wiper (Opt.)	Wiper Switch (Opt.)	Shut Down Module (Opt.)	Flasher (Opt.)	Right Front Lamp	Right Flasher Lamp (Opt.)	Engine Temperature Gauge	Fuel Gauge	Light Switch	Trans. Warning Light	Engine Warning Light	Fuse - Ignition
1F	Red	16	40FR	Black	16																				
10A	Black	12	40R	Black	16																				
10B	Black	12	41	Pink	16																				
12	Orange	16	42FL	Dk. Blue	16																				
12A	Orange	18	42FR	Dk. Blue	16																				
12B	Orange	12	42R	Dk. Blue/White	16																				
12C	Orange	16	46	Brown	16																				
12F	Orange	18	46L	Brown	16																				
12L	Orange	18	46R	Brown	16																				
12T	Orange	18	49F	Gray	16																				
19C	Red/White	16	49T	Gray	16																				
19F	Red/White	16	49V	Gray	16																				
19H	Red/White	18	60W	Black	16																				
19L	Red/White	16	66	Orange/Green	16																				
19S	Red/White	16																							
19W	Red/White	16																							
21R	White	16																							
21RM	White	16																							
23F	White/Black	16																							
26	Lt. Blue	16																							
28	Lt. Blue/Black	16																							
30	Black	16																							
30F	Black	16																							
30G	Black	16																							
30T	Black	16																							
31FP	Yellow	16																							
31P	Yellow/Green	18																							
32FPT	Yellow	18																							
32PT	Yellow	18																							
35H	Yellow/Brown	18																							
36	Purple	16																							
36T	Purple/White	18																							

● Tee splice
○ Butt splice

ENGINE HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
0	Black																					
1	Red	Cable																				
1A	Red	8																				
1B	Red	10																				
1C	Red	12																				
1D	Red	12																				
10A	Black	12																				
12C	White/Orange	16																				
14F	Lt. Green	16																				
14R	Lt. Green/White	16																				
21R	White	16																				
21S	White/Green	12																				
23F	White/Black	16																				
28	Lt. Blue/Black	16																				
28B	Lt. Blue/Orange	8																				
28S	Lt. Blue/Yellow	16																				
31P	Yellow/Lt. Green	16																				
32F	Yellow/Dk. Blue	16																				
32PT	Yellow	16																				
32T	Yellow/Black	16																				
35H	Yellow/Brown	16																				
36T	Purple/White	16																				
60B	Black	16																				
66	Orange/Green	16																				


PARTS LEGEND

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
Harness Connectors	Unfused & Live Accessories	Engine Connector	Back-Up Alarm Switch (Opt.)	Trans. Oil Temperature Switch	Trans. Charge Pressure Switch	Starter	Engine Oil Pressure Switch	Fuel Shut-Off Solenoid (Internal)	Hydraulic Fluid Filter Pressure Switch	Glow Plugs	Engine Coolant Temp. Sender	Diode	Alternator	Battery	Pre-Heat Relay	Start Relay	Frame Ground	Engine Ground

WIRING DIAGRAM (P/N 6570914)

843 (S/N 26001 Thru 28134)

(Printed July 1988)



* Wire 26LT is connected to wire 26 when module is not used.

CAB HARNESS

6570914 (7-88)

CAB HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	40FL	Black	16
1F	Red	16	40FR	Black	16
10A	Black	12	40R	Black	16
10B	Black	12	41	Pink	16
12	Orange	16	42FL	Dk. Blue	16
12A	Orange	18	42FR	Dk. Blue	16
12B	Orange	12	42R	Dk. Blue/White	16
12C	Orange	16	46	Brown	16
12F	Orange	18	46L	Brown	16
12L	Orange	18	46R	Brown	16
12T	Orange	18	49F	Gray	16
19C	Red/White	16	49T	Gray	16
19F	Red/White	16	49V	Gray	16
19H	Red/White	18	60W	Black	16
19L	Red/White	16	66	Orange/Green	16
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
21RM	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
28	Lt. Blue/Black	16			
30	Black	16			
30F	Black	16			
30G	Black	16			
30T	Black	16			
31FP	Yellow	16			
31P	Yellow/Green	18			
32FPT	Yellow	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			
36T	Purple/White	18			

PARTS LEGEND

1	Harness Connectors	21	Fuse - Accessory
2	Operator Cab Ground	22	Voltmeter
3	Fuel Sender	23	Ignition Switch
4	Back-Up Alarm (Opt.)	24	Hourmeter
5	Rear Lamp		
6	Tail Lamp	●	Tee splice
7	Left Flasher Lamp (Opt.)	○	Butt splice
8	Left Front Lamp		
9	Wiper (Opt.)		
10	Wiper Switch (Opt.)		
11	Shut Down Module (Opt.)		
12	Flasher (Opt.)		
13	Right Front Lamp		
14	Right Flasher Lamp (Opt.)		
15	Engine Temperature Gauge		
16	Fuel Gauge		
17	Light Switch		
18	Trans. Warning Light		
19	Engine Warning Light		
20	Fuse - Ignition		

ENGINE HARNESS

WIRE LEGEND

PARTS LEGEND

NO.'s	COLOR	GAUGE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
0	Black	Cable	Harness Connectors	Start Relay																	
1	Red	Cable	Unfused & Live Accessories	Frame Ground																	
1A	Red	8	Engine Connector	Engine Ground																	
1B	Red	10	Back-Up Alarm Switches (Opt.)																		
1C	Red	12	Trans. Oil Temperature Switch																		
1D	Red	12	Trans. Charge Pressure Switch																		
10A	Black	12	Starter																		
12C	White/Orange	16	Engine Oil Pressure Switch																		
14F	Lt. Green	16	Fuel Shut-Off Solenoid (Internal)																		
14R	Lt. Green/White	16	Hydraulic Fluid Filter Pressure Switch																		
21R	White	16	Glow Plugs																		
21S	White/Green	12	Engine Coolant Temp. Sender																		
23F	White/Black	16	Diode																		
28	Lt. Blue/Black	16	Alternator																		
28B	Lt. Blue/Orange	8	Battery																		
28S	Lt. Blue/Yellow	16	Pre-Heat Relay																		
31P	Yellow/Lt. Green	16																			
32F	Yellow/Dk. Blue	16																			
32PT	Yellow	16																			
32T	Yellow/Black	16																			
35H	Yellow/Brown	16																			
36T	Purple/White	16																			
60BA	Black	16																			
60B	Black	16																			
66	Orange/Green	16																			

CAB HARNESS


WIRE LEGEND

PARTS LEGEND

WIRING DIAGRAM (P/N 6570915)

843 (S/N 28135 & Above) & 843B

(Printed September 1990)



* Wire 26A is connected to wire 26 when module is not used.

CAB HARNESS

6570915

CAB HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE	NO.'s	COLOR	GAUGE
1D	Red	12	36T	Purple/White	18
1F	Red	16	40R	Black	16
10A	Black	12	40FL	Black	16
10B	Black	14	40FR	Black	16
10AB	Black	12	41	Pink	16
12A	Orange	18	42FL	Dk. Blue	16
12B	Orange	16	42FR	Dk. Blue	16
12C	Orange	16	42R	Dk. Blue/White	16
12F	Orange	16	46	Brown	16
12L	Orange	18	46L	Brown	16
12T	Orange	18	46R	Brown	16
12V	Orange	18	49F	Gray	18
19C	Red/White	16	49T	Gray	18
19F	Red/White	16	49V	Gray	18
19H	Red/White	18	60W	Black	16
19L	Red/White	16	66	Orange/Green	16
19S	Red/White	16			
19W	Red/White	16			
21R	White	16			
21RM	White	16			
23F	White/Black	16			
26	Lt. Blue	16			
26A	Lt. Blue	16			
28	Lt. Blue/Black	16			
30	Black	16			
30G	Black	16			
30T	Black	16			
31	Yellow	18			
31P	Yellow/Green	18			
32	Yellow	18			
32PT	Yellow	18			
35H	Yellow/Brown	18			
36	Purple	16			

PARTS LEGEND

1	Harness Connectors	19	Fuel Gauge
2	Ground	20	Hourmeter
3	Fuel Sender	21	Fuse (Ignition)
4	Back-Up Alarm (Opt. 843B Only)	22	Fuse (Accessory)
5	Rear Light (Opt. 843B Only)	23	Light Switch (Opt. 843B Only)
6	Tail Light (Opt. 843B Only)	24	Ignition Switch
7	Left Flasher Light (Opt.)		
8	Left Front Light (Opt. 843B Only)		
9	Wiper Switch (Opt.)		
10	Wiper (Opt.)		
11	Shut Down Module (Opt.)		
12	Flasher (Opt.)		
13	Right Front Light (Opt. 843B Only)		
14	Right Flasher Light (Opt.)		
15	Trans. Warning Light		
16	Engine Warning Light		
17	Voltmeter		
18	Temperature Gauge		

ENGINE HARNESS

WIRE LEGEND

NO.'s	COLOR	GAUGE
0	Black	Cable
1	Red	Cable
1A	Red	8
1B	Red	10
1C	Red	12
1D	Red	12
10A	Black	12
12C	White/Orange	16
14F	Lt. Green	16
14R	Lt. Green/White	16
21R	White	16
21S	White/Green	12
23F	White/Black	16
28	Lt. Blue/Black	16
28B	Lt. Blue/Orange	8
28S	Lt. Blue/Yellow	16
31P	Yellow/Lt. Green	16
32F	Yellow/Dk. Blue	16
32PT	Yellow	16
32T	Yellow/Black	16
35H	Yellow/Brown	16
36T	Purple/White	16
60BA	Black	16
60B	Black	16
66	Orange/Green	16

PARTS LEGEND

1	Harness Connectors	15	Battery
2	Unfused & Live Accessories	16	Pre-Heat Relay
3	Engine Connector	17	Start Relay
4	Back-Up Alarm Switch (Opt.)	18	Frame Ground
5	Trans. Fluid Temp. Switch	19	Engine Ground
6	Trans. Charge Pressure Switch		
7	Starter		
8	Engine Oil Pressure Switch		
9	Fuel Shut-Off Solenoid (Internal)		
10	Hydraulic Filter Pressure Switch		
11	Glow Plugs		
12	Engine Coolant Temp. Sender		
13	Diode		
14	Alternator		

6 ELECTRICAL SYSTEM

ELECTRICAL SYSTEM INFORMATION

Description

The loader has a 12 volt, negative ground electrical system. There are two main circuits.

1. The charging circuit has an alternator (with built-in regulator), a voltmeter and a battery.
2. The starting circuit has a starter motor, solenoids and other components for starting the engine.

The loader also has front and rear lights. Optional windshield wiper, horn and back-up alarm.

The electrical system is protected by two fuses installed in the instrument panel. Fuses protect the electrical system from an overload.

TROUBLESHOOTING

The following troubleshooting chart is provided as an assistance in locating and correcting problems which are most common. Many of the recommended procedures must be done by authorized Bobcat Service Personnel only.

PROBLEM	CAUSE
Battery does not charge.	1, 2, 3, 4, 5
Alternator will not charge.	1, 2, 5
Starter will not turn the engine.	2, 3, 4, 6, 7, 8, 9

KEY TO CORRECT THE CAUSE
<ol style="list-style-type: none"> 1. Alternator belt is loose or damaged. 2. Battery connections are dirty or loose. 3. Battery is damaged. 4. The ground connection is not making a good contact. 5. The alternator is damaged. 6. The engine is locked. 7. The starter is damaged. 8. The wiring or the solenoid is damaged. 9. Check the fuses.

WARNING

Instructions are necessary before operating or servicing machine. Read Operator's Manual, Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Failure to follow instructions can cause injury or death.

W-2003-1285

BATTERY


Checking the Battery

The tool listed will be needed to do the following procedure:

MEL-10004 — Battery Tester

To make a safe and complete check of the battery see the Clark Battery Manual (P/N 6566047).

The Battery Manual has all the information and specifications needed for checking and servicing the battery. Replace the battery as needed.




 **WARNING**

Batteries contain acid which burns eyes or skin on contact. Wear goggles and protective clothing and rubber gloves to keep acid off body.

In case of acid contact, wash immediately with water for several minutes and get medical attention.

W-2065-1285




DO NOT remove the vent caps from the battery while charging the battery. The battery has vent caps which will decrease the possibility of the battery being exploded by an external spark.

Removal and Installation

Disconnect the battery cables. Always remove the negative (–) cable first to prevent sparks **A**.

Remove the nuts and bolts from the holddown clamp and remove the holddown clamp **B**.

Remove the battery from the loader **C**.




ALTERNATOR

Alternator Belt Adjustment


Open the rear door.

Remove the bolts from the belt shield.

Remove the belt shield from the engine **A**.




Loosen the adjustment bolt **B**.



Move the alternator to set the belt tension at 1/4" (6,5 mm) deflection with 5 lbs. pressure **C**.

Tighten the adjustment bolt **B**.

Install the belt shield.



ALTERNATOR (Cont'd)

Checking the Alternator Wire Harness


Turn the key switch to the "ON" position and make the checks as follows **A**.

Connect a voltmeter between ground and No. 1 terminal.

Connect a voltmeter between ground and No. 2 terminal.

Connect a voltmeter between ground and "BAT" terminal.


If any of the tests show zero voltage, the wiring harness has a defect. Repair the wiring harness as needed.



Checking Alternator Output

Lift and block the loader (See Page 1-2 for the correct procedure).

Disconnect the "BAT" terminal at the alternator **B**.




Connect the "BAT" wire to one side of the ammeter. Connect the other side to the "BAT" terminal of the alternator **C**.

Disconnect the fuel shut-off wire at the injection pump. Turn the engine, with the starter for 30 seconds to lower the charge in the battery.

Connect the fuel shut-off wire.

Start the engine and run at full RPM.

The ammeter reading must be within 10% of rated amperage (37 amps. @ 2100 RPM) **C**.




Checking Alternator Regulator

Use the same procedure as above for "Checking Alternator Output" except for the following:

Put a small screwdriver in the test hole **D**.

The ammeter reading must be within 10% of rated amperage (37 amps. @ 2100 RPM).

If the reading is less than 10% of rated amperage, check the diode trio, rectifier, stator or rotor.




ALTERNATOR (Cont'd)

Removal and Installation


Remove the belt shield at the engine.

Disconnect the negative (-) cable at the battery.


Disconnect the wire at the "BAT" terminal **A**.



Disconnect the No. 1 & 2 terminals **B**.




Remove the adjustment bolt **C**.




Remove the mounting bolt **D**.

Remove the alternator from the engine.



A

1. Pulley
2. Bolts
3. Case Halves
4. Rotor
5. Nuts
6. Stator
7. Diode Trio
8. Rectifier
9. Capacitor
10. Brush Holder
11. Regulator



C-1802

ALTERNATOR (Cont'd)**Disassembly and Assembly**

Disassemble the alternator as shown **A**.

Connect an ohmmeter as follows to check the rotor **B**.

Between one slip ring and the shaft. Check the other slip ring. There must be maximum resistance.


Between both slip rings. There must be 2.4 to 3.0 ohms resistance.

Connect a battery powered test light as follows to check the stator **C**.


Between the center wire and an outside wire. Light must come "ON".

Between center wire and the other outside wire. Light must come "ON".

Between one of the wires and frame. Light must NOT come "ON".



B-8068



B-2108

ALTERNATOR (Cont'd)

Connect a D.C. test light as follows to check the diode trio **A**.

IMPORTANT

Do not use voltage which is more than circuit voltage to check the diode trio or the rectifier.

I-2026-0284

Between a single connection and one of the three connections. Connect the tester in the opposite direction. The light must come "ON" in one direction, but not in the other direction.

Check each diode with the same procedure.

Connect a test light as follows to check the rectifier **B**.

Between one connection and insulated heat sink. Connect the test light in opposite direction. The light must come "ON" in one direction, but not in the other direction.


Between one connection and the grounded heat sink. Connect test light in opposite direction. The light must come "ON" in one direction, but not in the other direction.

Assembly: Reverse the order of disassembly.


Also if regulator was removed, install new insulated washers and spacers **C**.

When installing the brushes, put a piece of straight wire through the housing to hold the brushes in the up position **D**.


Then install the rotor, when in position pull the wire out to seat the brushes.




A-2382



B-2101
B-2102



B-2128



B-2097

MELROE ALTERNATOR

Checking the Alternator Output



WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286

Lift and block the loader (Refer to Page 1–2 for the correct procedure).

Disconnect the negative (–) cable from the battery.

Remove the belt shield.

Connect the orange lead (Item 1) from the alternator output terminal to the negative (–) side of the ammeter. Connect the positive (+) side of the ammeter to the output terminal on the alternator (Item 2) **A**.

Disconnect the fuel shut-off wire.

Connect the negative (–) cable to the battery.

Turn on the lights and crank the engine for 30 seconds to run the battery down.



Connect the fuel shut-off wire.

Start the engine and run at 2600 R.P.M.

The ammeter reading should be between 45 & 55 amps. @ 2600 RPM.

If the reading is low, disconnect the battery and connect a jumper wire from the alternator output terminal (Item 1) to the regulator terminal (Item 2).

Connect the battery cable, start the engine and check the ammeter. If the reading is within the rated amperage (45-55 amps. @ 2600 RPM) replace the diode trio **B**.



Checking the Alternator Regulator

Connect the positive (+) voltmeter lead to the positive (+) battery terminal and connect the negative (-) voltmeter lead to the negative (-) battery terminal **A**.

WARNING

Put jackstands under the front axles and rear corners of the frame before running the engine for service. Failure to use jackstands can allow the machine to fall or move and cause injury or death.

W-2017-0286

WARNING

When an engine is running in an enclosed area, fresh air must be added to avoid concentration of exhaust fumes. If the engine is stationary, vent the exhaust outside. Exhaust fumes contain odorless, invisible gases which can kill without warning.

W-2050-1285

Start and run the engine at 1500 - 2000 R.P.M. The voltmeter should be between 13.9 - 14.7 volts **A**.



If the reading is low, stop the engine and disconnect the battery.

Remove the screws and pull the regulator cover away from the alternator. Connect the jumper wire from the ground stud (Item 1) to the brush terminal (Item 2) (the tan wire) **B**.

Connect the battery and start the engine. Run at 1500 RPM. DO NOT allow the meter to exceed 16 volts.

If the reading is 14.5 or above, replace the regulator.

If the reading is 14.5 or below, repair or replace the alternator.




MELROE ALTERNATOR (Cont'd)

Removal and Installation

Disconnect the negative cable from battery.


Disconnect the wire terminals from the back of the alternator **A**.



Disconnect the battery terminal **B**.

Remove the adjustment bolt and the mounting bracket bolt.

Remove the alternator.



WARNING


AVOID INJURY

Never service or adjust the machine when the engine is running unless instructed to do so in the manual.

W-2012-1285

A

1. Nut
2. Pulley
3. Fan
4. Bolt
5. Case Half (Front)
6. Bearing
7. Rotor
8. Slip Ring
9. Stator
10. Heat Sink (+)
11. Heat Sink (-)
12. Case Half (Rear)
13. Condenser Assy.
14. Brush Holder Kit
15. Regulator Kit



D-1760

MELROE ALTERNATOR (Cont'd)**Disassembly and Assembly**

Disassemble the alternator as shown **A**.

Remove three (3) bolts (Item 4) holding halves together.

Pry halves apart.

Use a soft jaw vise to hold rotor while removing pulley nut (Item 1).


Remove front case half (Item 5) from the rotor using a plastic hammer or press.

Unsolder the stator wires from the rectifier to test the stator and rectifier. Use a needle nose plier to aid in removal of the wires.


Use the following procedure with an ohmmeter to test the rotor:

Touch both probes on the slip rings. There must be a 3 to 5 ohm reading **B**.

Touch one probe to the shaft and one probe to a slip ring, then to the other. There must be maximum resistance **C**.



B-9375




B-9376


MELROE ALTERNATOR (Cont'd)

Use the following procedure with an ohmmeter to test the stator:

Touch to (2) bare wires of the stator with the probes, take a reading. Move one probe to the other wire. The readings should be the same **A**.




Test for ground by touching one probe on the metal surface of the stator and the other probe on the bare wire. There must be no needle movement **B**.




Use the following procedure with a circuit tester to test the rectifier:

Touch the positive probe to the positive diode holder and the negative probe to each diode terminal. There must be continuity **C**.




Reverse the probes and check the other direction. There must be no continuity **D**.



MANDO ALTERNATOR (Cont'd)


Touch the negative probe to the negative diode holder and the positive probe to each diode terminal. There must be continuity **A**.



Reverse the probe and check the other direction. There must be no continuity **B**.


Check the brushes for wear. The maximum length of exposed brushes should be .125" (3 mm).

Replace broken or rusted brush springs.



Reverse the order of disassembly.

Place the rotor in soft jaws when tightening the shaft nut. Tighten to 50 ft.-lbs. (70 Nm) torque **C**.



STARTER

Checking the Starter


The key switch must be in the "OFF" position.

The battery must be at full charge.

The cable connections must be clean and tight.

Connect a jumper wire between "S" terminal and "BAT" terminal **A**.


If the starter turns but does not turn the engine, the starter drive has a defect.



Connect a jumper wire between the "M" terminal and the "BAT" terminal **B**.

If the starter turns, the defect is in the solenoid.


If the starter does not turn, the starter is defective.




Removal and Installation

Disconnect the negative (-) cable at the battery.

Disconnect the wire at the "BAT" terminal of the solenoid **C**.




Disconnect the wires at the solenoid **D**.




STARTER (Cont'd)


Remove the bolts at the starter bracket **A**.



Remove the starter mounting bolts **B**.




Remove the starter from the engine **C**.



A

1. Bolt, solenoid
2. Solenoid
3. Spring, plunger
4. Pin, plunger/shift fork
5. Plunger
6. Shift Fork
7. Bolt, shift fork pivot
8. Bolt, end cap
9. End Cap
10. Shim Washer
11. Armature
12. Thrust Washer
13. Drive Assembly
14. Drive Stop Ring
15. Thrust Collar
16. Bushing
17. Field Coils
18. Brush



C-1802

STARTER (Cont'd)**Disassembly and Assembly**Disassemble the starter as shown **A**.**WARNING**

Wear safety glasses to prevent eye injury when any of the following conditions exist:


- When fluids are under pressure.
- Flying debris or loose material is present.
- Engine is running.
- Tools are being used.

W-2019-1285


Cleaning and Inspection

Use a brush and air pressure to clean the drive, field coils, armature and starter housing.

NOTE: Do not use solvent to clean the drive assembly. The solvent will remove the lubricant and the drive will slip.

B

A-1995

C

A-1994

STARTER (Cont'd)

Check the following items:

Armature

To check the armature for grounds, place one probe from the ammeter on the iron core and one probe on the commutator. The test lamp should not light Page 6-14 **A**.

To check for open circuit, place the armature on a growler as shown. Place a hacksaw blade on the armature. If the hacksaw blade vibrates while the armature rotates, the winding is short circuited and must be replaced Page 6-14 **B**.

Also check:

- Broken or burned insulation
- Loose connections at commutator
- Worn shaft or bearings
- Rough commutator

Brush Holders

- Brush springs
- Broken insulation
- Spring tension

Field Coils

To test for a continuity, disconnect the field winding ground connections. Touch one probe to the field connector and one probe to the brush. The lamp should not light **A**.

To test for ground, touch one probe to the body and the other probe to the field windings end of the brush. The lamp should not light **B**.

Also check:

- Broken or burned insulation
- Brush connections
- Brushes

Drive Gear

- Worn teeth
- Tooth engagement (Drive gear must engage ring gear by 1/2 the depth of ring gear teeth)

Replacing the Brushes

Remove the brush screw and remove the brush. Replace the brush wire by screws or by cutting the old wire. Solder the new brush wire to the ends of the old wire, or screw the wire in place.

Assembly: Reverse the order of disassembly.

Put a small amount of grease on the splines of the armature and the bushings.

