



# 2005 RG 2.5L / 2.8L DIESEL ENGINE

## SERVICE MANUAL SUPPLEMENT

NO PART OF THIS PUBLICATION MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM, OR TRANSMITTED, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING, OR OTHERWISE, WITHOUT THE PRIOR WRITTEN PERMISSION OF DAIMLERCHRYSLER CORPORATION.

DaimlerChrysler Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

Copyright © 2004 DaimlerChrysler Corporation

# FOREWORD

This manual is designed as a supplement to be used along with the 2005 Voyager Service Manual. It includes information related to the 2.5L / 2.8L diesel engine installed in this vehicle by DaimlerChrysler Corporation. For diagnosis or service procedures relating to other components or systems, refer to the 2005 Voyager Service Manual.

The information contained in this service manual has been prepared for the professional automotive technician involved in daily repair operations. Information describing the operation and use of standard and optional equipment is included in the Owner's Manual provided with the vehicle.

Information in this manual is divided into groups. These groups contain description, operation, diagnosis, testing, adjustments, removal, installation, disassembly, and assembly procedures for the systems and components. The first page of the group has a contents section that lists major topics within the group.

A Service Manual Comment form is included at the rear of this manual. Use the form to provide DaimlerChrysler Corporation with your comments and suggestions.

Tightening torques are provided as a specific value throughout this manual. This value represents the midpoint of the acceptable engineering torque range for a given fastener application. These torque values are intended for use in service assembly and installation procedures using the correct OEM fasteners. When replacing fasteners, always use the same type (part number) fastener as removed.

DaimlerChrysler Corporation reserves the right to change testing procedures, specifications, diagnosis, repair methods, or vehicle wiring at any time without prior notice or incurring obligation.

## GROUP TAB LOCATOR

3a Differential & Driveline

6a Clutch

7a Cooling

8Ea Electronic Control Modules

8Ia Ignition Control

9a Engine

11a Exhaust System

14a Fuel System

21a Transmission/Transaxle

25a Emissions Control

**Service Manual Comment Forms**

**(Rear of Manual)**

